



All About the Status bar of W10M

Status bar is the top bar displaying the system indicators (Battery, Celluler, WiFi, etc..).



This Guide will layout the meanings of all the Icons in Status bar.

Mobile Signal Signs



Signal strength



Your phone isn't connected to a mobile network.



There is no SIM card in your phone.



Your SIM card is locked.



Flight mode is switched on.



Your phone is roaming outside your home mobile network.





Call Forwarding Sign



Your calls are forwarded to another number or your voice mailbox.

Mobile Data Signs

E

An EDGE data connection is open.

G

A GPRS data connection is open.

3G

Your phone is connected to a 3G network.

H

A high-speed (HSDPA/HSUPA) data connection is open.

H+

A high-speed (HSPA+/DC-HSDPA) data connection is open.

4G

Your phone is connected to a 4G network.



Data is transferred over a mobile data connection.





WiFi Connection Signs



A WiFi connection is active.



A mobile data connection is shared with other devices over WiFi.



Data is transferred over WiFi.

Bluetooth Peripherals Sign



A Bluetooth device is connected to your phone.

Device Battery Signs



Battery power level



The battery is charging.



Battery saver mode is switched on.



Battery power or state of the battery isn't currently known.





Notifications Sign



You have unread notifications, such as new messages.
To check the notifications, swipe down from the top of the screen.

Different Profiles Signs



Vibrate mode is switched on.



Silent mode is switched on.

Cortana Signs



Quiet hours mode is switched on and Cortana is handling your calls and messages.

Location Sign



An app or service is using your location info.

Driving Mode Sign



Driving mode is switched on.

